

Nitro RC / Shuts off with plenty of fuel

Your engine is running too lean. The engine runs hot and shuts off by itself because the piston has grown too large to be able to move up and down in the cylinder.

The high-speed needle valve must be opened so more fuel gets to the engine. Running an engine lean may produce a little higher performance initially, but will ruin the engine eventually. screw the high speed needle out anticlockwise in small increments